Reinigungs- und Pflegehinweise für Mehrwegprodukte

Damit unsere Produkte über viele Jahre ihre Haltbarkeit & Transparenz behalten, sollten Sie folgende Punkte beachten. Produkte aus Polypropylen (PP) und Polycarbonat (PC) können auf die gleiche Art und Weise wie gewöhnliche Trinkgläser gereinigt werden, von Hand oder in einer handelsüblichen oder industriellen Spülmaschine.

Vor der ersten Verwendung

- Reinigen Sie alle Produkte mit heißem Wasser und einem Glasreiniger
- Nutzen Sie zum Nachpolieren spezielle Microfasertücher

Handwäsche

- Bei einer Handwäsche empfiehlt sich einen Microfaser Schwamm, eine weiche Spülbürste oder ein Mikrofasertuch
- Hartnäckige Flecken oder kleine Kratzer können Sie mit der rauen Seite eines Microschwamms unter fließendem Wasser entfernen
- Lippenstifte entfernen Sie am besten rückstandslos mit einem Mikrofasertuch

Maschinenwäsche

- Die Reinigung im Geschirr- oder Industriespülmaschine ist möglich
- Wir empfehlen Spülmittel mit Reiniger & Klarspüler, da andere Reiniger meist nicht für Kunststoffe geeignet sind
- Produkte sollten bei 65 bis 75 Grad gewaschen werden
- Wir garantieren bei oben genannten Temperaturen bis zu 1000 Spülgänge nach DIN EN 12875-2:2002-03
- Um Wasserflecken zu vermeiden empfehlen wir Klarspüler oder eine verlängerte Trockung in der Maschine

Pflegeempfehlung bei kalkhaltigem Wasser

- Bei sehr hartem oder kalkhaltem Wasser empfiehlt sich eine Osmoseanlage
- Verwenden Sie spezielle Glasreiniger und Klarspüler, diese sind für Kunststoffgläser optimiert, reinigen aber auch normales Glas und Geschirr

Bitte vermeiden!

Folgende Punkte können die Haltbarkeit, Klarheit und die Lebensdauer verkürzen

- Über einen längeren Zeitraum über 75 Grad waschen
- Überdosierung von Klarspülern
- Leck im Osmose-System
- **Benutzung von Spülmittel mit Metallschutz · Benutzung der falschen Geschirrspülmaschinenvorrichtung**
- Benutzung von falschen Poliertüchern oder Reinigungsschwämmen verursachen Kratzspuren
- Milchprodukte / Getränke können Rückstände hinterlassen, wenn das Glas nicht mit heißem Seifenwasser nach Gebrauch gewaschen wird.
- **Die Benutzung von Liquid Ecstasy oder andere Drogen**
  Unsere Produkte reagieren auf GHB oder GBL. Sollten Kunden diese Substanzen in die Gläser füllen bzw. mischen, entstehen kleine weiße Flecken und Schlieren, die sich fest im Glas absetzen.

Das schadet den Produkten!

- **Verwendung von Anis-Getränken (Pernod, Anis, Ricard, Raki und Ouzo)** bei PC Gläsern
- Scheuermittel, Stahlwolle, Rasierklingen oder andere scharfe Gegenstände verwenden
- Polycarbonat nicht mit Benzin, Reiniger, Ester oder organischen Lösungsmitteln reinigen
- Nur Produkte stapeln, die auch dafür geeignet sind!
- Sand zwischen den Gläsern
- Feuer & Zigaretten zerstören die Oberfläche
- Gläser nur stehend transportieren, nicht liegend

Cleaning and care instructions for reusable products

To ensure that our products retain their durability and transparency for many years, you should follow the following points observe. Polypropylene (PP) and polycarbonate (PC) products can be cleaned in the same way as regular drinking glasses, by hand or in a commercial or industrial dishwasher.

Before first use

- Clean all products with hot water and a glass cleaner
- Use special microfiber cloths for polishing

Hand wash

- When washing by hand, we recommend using a microfiber sponge, a soft dishwashing brush or a microfiber cloth
- You can remove stubborn stains or small scratches with the rough side of a micro-sponge under running water
- The best way to remove lipstick without leaving any residue is to use a microfiber cloth

Machine wash

- Cleaning in a dishwasher or industrial dishwasher is possible
- We recommend dishwashing liquid with cleaner and rinse aid, as other cleaners are usually not suitable for plastics
- Products should be washed at 65 to 75 degrees
- We guarantee up to 1000 wash cycles in accordance with DIN EN 12875-2:2002-03 at the above-mentioned temperatures
- To avoid water stains, we recommend using rinse aid or prolonged drying in the machine

Care recommendation for hard water

- If the water is very hard or contains lime, an osmosis system is recommended
- Use special glass cleaners and rinse aids, these are optimized for plastic glasses, but also clean normal glass and dishes

Please avoid!

The following points can shorten durability, clarity and lifespan

- Wash above 75 degrees for a longer period of time
- Overdose of rinse aid
- Leak in the osmosis system
- **Using detergent with metal protection · Using the wrong dishwasher device**
- Using the wrong polishing cloths or cleaning sponges will cause scratches
- Dairy products/drinks may leave a residue if the jar is not washed with hot, soapy water washed after use.
- **The use of liquid ecstasy or other drugs**
  Our products react to GHB or GBL. If customers fill or mix these substances into the glasses, small white spots and streaks are created that settle firmly in the glass.

This damages the products!

- **Use of aniseed drinks (Pernod, Anis, Ricard, Raki and Ouzo)** with PC glasses
- Use abrasive cleaners, steel wool, razor blades or other sharp objects
- Do not clean polycarbonate with gasoline, cleaners, esters or organic solvents
- Only stack products that are suitable for this purpose!
- Sand between the glasses
- Fire & cigarettes destroy the surface
- Only transport glasses standing, not lying down